

Register your product and get support at

www.philips.com/welcome







42PFL7409/98
47PFL7409/98
42PFL7409S/98
47PFL7409S/98







Quick

Start


PHILIPS



1




2










3


1




2









4





HDMI	
☆☆☆☆	
YPbPr & AUDIO L/R	
☆☆☆	
S-VIDEO & AUDIO L/R	
☆☆	









www.philips.com/support



Specifications are subject to change without notice
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners
2009 © Koninklijke Philips Electronics N.V. All rights reserved.



3139 125 41091